















- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod





A**S504-LAW_4_11**

2 / 5


**45 min**

A	B	C1	C2	C3	D
1	S168-121	361	646	22	1/1
2	S168-322	1044	600	8	1/1
3	S168-583	648,	23	12,	1/1
4	S188-703	1103	247,	22	1/1
5	S188-704	1103	156	19	1/1
6	S504-4015	1052	80	15	1/1










3



4



5



Pflegehinweis!

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!