



























- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod









A	B	C1	C2	C3	D
1	S504-0025	200	496	16	1/1
2	S504-0026	200	496	16	1/1
3	S504-1032	377	390	15	1/1
4	S504-1033	377	390	15	1/1
5	S504-2019	500	390	15	1/1
6	S504-2020	500	390	15	1/1
7	S504-5709	469,	68	16	1/1
8	S504-9002	387,	479,	2,5	1/1
9	WSP-9257	439,	358	2,5	1/1
10	ZQ6-5044	429	97	15	1/1
11	ZQ6-519	350	110	12	1/1
12	ZQ6-520	350	110	12	1/1
13	S504-4031	469,	68	15	1/1













6




6






7



8



### Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

### Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

