











- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod










A

S504-SFK4D/8/11






A	B	C1	C2	C3	D
1	S504-0009	403	521	16	2/2
2	S504-0010	403	521	16	2/2
3	S504-1005	783,	390	15	1/2
4	S504-1006	783,	390	15	1/2
5	S504-1007	783,	354,	15	1/2
6	S504-2005	1050	390	15	1/2
7	S504-2006	1050	390	15	1/2
8	S504-5701	1019	68	16	1/2
9	S504-9301	1029	793,	2,5	1/2
10	S504-3001	502,	354,	15	1/2
11	S504-4034	1019	68	15	1/2









4






5




6



7




8



11

180°

11




8

4

5

3




8

d41/2

p38

p38




11

d41/2


p38

p38



9



10



11

**Pflegehinweis!**

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!

