



























- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod










A	B	C1	C2	C3	D
1	S504-1011	986	330	15	1/2
2	S504-1012	986	330	15	1/2
3	S504-2009	600	330	15	1/2
4	S504-3002	569	300	15	1/2
5	S504-3003	562	280	4	1/2
6	S504-5551	469,	564	3,	2/2
7	S504-5705	345	100	6,	1/2
8	S504-7301	403	596	16	2/2
9	S504-7302	200	596	16	2/2
10	S504-9303	996	579	2,5	1/2
11	qc33/1				1/2
12	S504-7352	345	100	6,	1/2

























2








8 §11



9



Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

